

Continue























MA0303-A About This Manual General Guide

Σ Press C to change from mode to mode. After you perform an operation (except for B) in any mode, pressing C returns to the Timekeeping Mode.

Σ In any mode, press B to illuminate the display.

Timekeeping Mode

Timekeeping This watch features separate digital and analog timekeeping. The procedures for setting the digital time and analog time are different.

Σ In the Timekeeping Mode, press A to toggle the display between the date screen and the time screen.

Date Screen Hour hand Day of week Month - Day Digital Time and Date Use the Timekeeping Mode to set and view a digital display of the current time and date. When setting the digital time, you can also configure settings for summer time (Daylight Saving time or DST). To set the digital time and date

Seconds Day 3. When the setting you want to change is flashing, use B and D to change it as described below.

Screen To do this: FA Reset the seconds to Toggle between Daylight Saving Time ( OFF and Standard Time ( P 10:08

Change the hour or minutes. Change the year. CAAD 6-30 Change the month or day.

4. Press A to exit the setting screen.

Σ Resetting the seconds only (without changing the hour, minute, or DST setting) causes the analog minute hand setting to be adjusted automatically. If you change the hour, minute, or DST setting, you should also use the procedure under "To adjust the analog time" to adjust the analog hands accordingly.

Σ See "Digital Time Daylight Saving Time (DST) Setting" for details about the DST setting.

Σ Resetting the seconds to causes the minutes to be increased by 1.

In the range of 00 to 29, the seconds are reset to AA without changing the minutes.

Σ The day of the week is automatically displayed in accordance with the date (year, month, and day) settings.

Σ The year can be set in the range of 2000 to 2099.

Σ The watch's built-in full automatic calendar makes allowances for different month lengths and leap years. Once you set the date, there should be no reason to change it except after you have the watch's battery replaced.

USER'S GUIDE 2747

Σ Button operations are indicated using the letters shown in the illustration.

Σ Each section of this manual provides you with the information you need to perform operations in each mode. Further details and technical information can be found in the "Reference" section.

Telememo Mode

World Time Mode

Press C. Time Screen Minute hand Press A. PM indicator 1. In the Timekeeping Mode, hold down A until the seconds start to flash, which indicates the setting screen.

2. Press C to move the flashing in the sequence shown below to select the other settings.

DST Hour Minutes Year Month Do this: Press D. AA . ) Press D. ON ). OFF Use D (+) and B (-), while the current count is in the range of 30 to 59

AA Alarm Mode To toggle between 12-hour and 24-hour timekeeping In the Timekeeping Mode, press D to toggle between 12-hour timekeeping (indicated by A or P on the display), or 24-hour timekeeping.

Σ With the 12-hour format, the P (PM) indicator appears on the display for times in the range of noon to 11:59 p.m. and the A (AM) indicator appears for times in the range of midnight to 11:59 a.m.

Σ With the 24-hour format, times are displayed in the range of 0:00 to 23:59, without any indicator.

Seconds Σ The 12-hour/24-hour timekeeping format you select in the Timekeeping Mode is applied in all modes.

Digital Time Daylight Saving Time (DST) Setting Daylight Saving Time (summer time) advances the digital time setting by one hour from Standard Time. Remember that not all countries or even local areas use Daylight Saving Time.

Hour : Minutes To toggle the Timekeeping Mode digital time between DST and Standard Time Setting the Analog Time Perform the procedure below when the time indicated by the analog hands does not match the time of the digital display.

To adjust the analog time Σ If you need to advance the analog time a long way, press D and B at the same time. This locks the high speed hand movement, so you can release the two buttons. High-speed hand movement continues until you press any button. It will also stop automatically after the time advances 12 hours or if an alarm (daily alarm, Hourly Time Signal, or countdown alarm) starts to sound.

4. Press A to exit the setting screen.

Σ To return to the Timekeeping Mode, press C.

Countdown Timer Stopwatch Mode Hand Setting Mode Mode 1. In the Timekeeping Mode, hold down A until the seconds start to flash, which indicates the setting screen.

2. Press C once to display the DST setting screen.

3. Press D to toggle between Daylight Saving Time ( displayed) and Standard Time ( ON 4. Press A to exit the setting screen.

Σ The DST indicator appears on the Timekeeping, Alarm, and Hand Setting Mode to indicate that Daylight Saving Time is turned on.

1. In the Timekeeping Mode, press C six times to enter the Hand Setting Mode.

2. Hold down A until the current digital time starts to flash, which indicates the analog setting screen.

3. Press D to advance the analog time setting by 20 seconds.

Σ Holding down D advances the analog time setting at high speed. displayed).

OFF 1 Jupiterimages/Brand X Pictures/Getty Images

The casio telememo 30 is a multifunction wrist watch that allows you to save the names and telephone numbers of up to 30 people. In addition to the Telememo function, Casio Telememo 30 watches offer accurate digital and analog timekeeping, as well as features such as multiple alarms. Despite all of its features, learning to use your Casio Telememo 30 wrist watch is a simple process that takes just minutes. Set the digital time on your Casio Telememo 30 watch. Press and hold the top left button until the seconds digits flash, indicating that you have accessed the time-setting screen. Press the bottom right button to reset the seconds to "00" and then press the bottom left button to advance the flashing to the hours digits. Adjust the hours digits to the desired time using the top and bottom right buttons. Press the bottom left button to advance the flashing to the minutes digits, and set them to the desired time with the top and bottom right buttons. Press the top left button to exit the time-setting screen. Set the analog time on your Casio Telememo 30 wrist watch. Press the bottom left button six times in quick succession to access the hand-setting mode on the watch. Press and hold the top left button until the digital time display begins to flash, indicating that you have accessed the analog time-setting screen. Press the bottom right button repeatedly to advance the hands by a few seconds each time; hold down the button to advance the hands more quickly. Release the button when the watch hands reflect the desired time. Press the top left button to exit the settings screen and the bottom left button to return to regular timekeeping mode. Save a new Telememo record in your Casio Telememo 30 watch. Press the bottom left button to access the Telememo mode. Press and hold the top and bottom right buttons to access the new data screen. Hold down the top left button until a blinking cursor appears in the name field. Use the top and bottom right buttons to scroll through the alphabet until the desired letter is displayed. Press the bottom left button to move the cursor to the right. When the name is finished, press the bottom left button repeatedly until the cursor moves to the number field. Use the same process that you used to input the name to input the telephone number. Press the top left button to save the data. Review previously saved Telememo records on your Casio Telememo 30. Access Telememo mode by pressing the bottom right button repeatedly. Press the bottom right button to scroll through the Telememo records. Note that only the name is displayed for each record; press the top left button to view the related number. Set an alarm on your Casio Telememo 30. Press the bottom left button to access the alarm mode. Press the bottom right button to select which of the three alarm screens you want to set. Press and hold the top left button to enter the settings screen for your chosen alarm. Use the top and bottom right buttons to set the alarm to the desired time. Press the top left button to save your alarm and exit the settings screen. Por megan mattingly-arthur Fija la hora digital en tu reloj Casio Telememo 30. Mantén pulsado el botón de arriba a la izquierda hasta que los segundos parapadean, lo que indica que se ha accedido a la pantalla de puesta en hora. Presiona el botón inferior derecho para reposicionar los segundos a "00" y luego presiona el botón inferior izquierdo para avanzar en el parpadeo de los dígitos de las horas. Ajusta los dígitos de las horas hasta el tiempo deseado usando los botones de la derecha superior e inferior. Presiona el botón inferior izquierdo para avanzar en el parpadeo de los dígitos de los minutos, y ponlos a la hora deseada con los botones de la derecha superior e inferior. Pulsa el botón de arriba a la izquierda para salir de la pantalla de puesta en hora. Paso 2 Ajusta la hora analógica en tu reloj de pulsera Casio Telememo 30. Presiona el botón inferior izquierdo seis veces en sucesión rápida para acceder al modo de ajuste de mano en el reloj. Mantén pulsado el botón de arriba a la izquierda hasta que la pantalla digital de tiempo comience a destellar, lo cual indica que has accedido el análogo de ajuste de tiempo de pantalla. Presiona el botón de abajo a la derecha repetidamente para avanzar en las manos por unos segundos cada vez, mantén pulsado el botón para avanzar en las manos más rápidamente. Suelta el botón cuando las manecillas del reloj reflejan el tiempo deseado. Pulsa el botón de arriba a la izquierda para salir de la pantalla de configuración y el botón de abajo a la izquierda para volver al modo de hora normal regular. Paso 3 Guarda un registro de telememo nuevo en tu reloj Casio Telememo 30. Presiona el botón de abajo a la izquierda para acceder al modo de Telememo. Presiona y mantén presionados los botones superior e inferior derechos para acceder a la pantalla de datos nuevos. Mantén pulsado el botón de arriba a la izquierda hasta que un cursor parpadeante aparezca en el campo Nombre. Utiliza los botones de la derecha arriba y abajo para desplazarte por el alfabeto hasta la letra que desees. Presiona el botón inferior izquierdo para mover el cursor hacia la derecha. Cuando el nombre se termine, pulsa el botón inferior izquierdo en forma repetida hasta que el cursor se mueva al campo de número. Utiliza el mismo proceso que utilizaste para introducir el nombre que escribiste para el número de teléfono. Pulsa el botón superior izquierdo para guardar los datos. Paso 4 Revisa los registros previamente guardados del telememo sobre tu Casio Telememo 30. Accede al modo de telememo pulsando el botón de abajo a la derecha varias veces. Presiona el botón de abajo a la derecha para desplazarte a través de los registros del telememo. Ten en cuenta que sólo se muestra el nombre de cada registro y el botón de arriba a la izquierda para ver el número correspondiente. Paso 5 Configura una alarma en tu Casio Telememo 30. Presiona el botón de abajo a la izquierda para acceder al modo de alarma. Presiona el botón de abajo a la derecha para seleccionar cuál de las tres pantallas de alarma deseas configurar. Mantén pulsado el botón de arriba a la izquierda para entrar en la pantalla de ajustes de la alarma seleccionada. Utiliza los botones de la derecha arriba y abajo para ajustar la alarma a la hora deseada. Pulsa el botón superior izquierdo para guardar la alarma y salir de la pantalla de ajustes. Σ Button operations are indicated using the letters shown in the illustration. Σ Each section of this manual provides you with the information you need to perform operations in each mode. Further details and technical information can be found in the "Reference" section. Σ Press C to change from mode to mode. After you perform an operation (except for B) in any mode, pressing C returns to the Timekeeping Mode. Σ In any mode, press B to illuminate the display. This watch features separate digital and analog timekeeping. The procedures for setting the digital time and analog time are different. Σ In the Timekeeping Mode, press A to toggle the display between the date screen and the time screen. Date Screen Time Screen Day of week Month - Day Hour : Minutes PM indicator Minute hand Hour hand Seconds Use the Timekeeping Mode to set and view a digital display of the current time and date. When setting the digital time, you can also configure settings for summer time (Daylight Saving time or DST). To set the digital time and date 1. In the Timekeeping Mode, hold down A until the seconds start to flash, which indicates the settings screen. 2. Press C to move the flashing in the sequence shown below to select the other settings. To toggle between 12-hour and 24-hour timekeeping In the Timekeeping Mode, press D to toggle between 12-hour timekeeping (indicated by A or P on the display), or 24-hour timekeeping. Σ With the 12-hour format, the P (PM) indicator appears on the display for times in the range of noon to 11:59 p.m. and the A (AM) indicator appears for times in the range of midnight to 11:59 a.m. Σ With the 24-hour format, times are displayed in the range of 0:00 to 23:59, without any indicator. Σ The 12-hour/24-hour timekeeping format you select in the Timekeeping Mode is applied in all modes. Digital Time Daylight Saving Time (DST) Setting Daylight Saving Time (summer time) advances the digital time setting by one hour from Standard Time. Remember that not all countries or even local areas use Daylight Saving Time. To toggle the Timekeeping Mode digital time between DST and Standard Time 1. In the Timekeeping Mode, hold down A until the seconds start to flash, which indicates the settings screen. 2. Press C once to display the DST setting screen. 3. Press D to toggle between Daylight Saving Time (ON displayed) and Standard Time (OFF displayed). 4. Press A to exit the setting screen. Σ The DST indicator appears on the Timekeeping, Alarm, and Hand Setting Mode to indicate that Daylight Saving Time is turned on. Perform the procedure below when the time indicated by the analog hands does not match the time of the digital display. To adjust the analog time 1. In the Timekeeping Mode, press C six times to enter the Hand Setting Mode. 2. Hold down A until the current digital time starts to flash, which indicates the analog setting screen. 3. Press D to advance the analog time setting by 20 seconds. Σ Holding down D advances the analog time setting at high speed. Press C. Timekeeping Mode Telememo Mode World Time Mode Alarm Mode Countdown Timer Mode Stopwatch Mode Hand Setting Mode Press A. DST Seconds Day Hour Year Month Minutes 3. When the setting you want to change is flashing, use B and D to change it as described below. Screen FA OFF P 10:08 CAAD 6-30 To do this: Reset the seconds to AA. Toggle between Daylight Saving Time (ON) and Standard Time (OFF). Change the hour or minutes. Change the year. Change the month or day. Do this: Press D. Press D. Use D (+) and B (-). 4. Press A to exit the setting screen. Σ Resetting the seconds only (without changing the hour, minute, or DST setting) causes the analog minute hand setting to be adjusted automatically. If you change the hour, minute, or DST setting, you should also use the procedure under "To adjust the analog time" to adjust the analog hands accordingly. Σ See "Digital Time Daylight Saving Time (DST) Setting" for details about the DST setting. Σ Resetting the seconds to AA while the current count is in the range of 30 to 59 causes the minutes to be increased by 1. In the range of 00 to 29, the seconds are reset to AA without changing the minutes. Σ The day of the week is automatically displayed in accordance with the date (year, month, and day) settings. Σ The year can be set in the range of 2000 to 2099. Σ The watch's built-in full automatic calendar makes allowances for different month lengths and leap years. Once you set the date, there should be no reason to change it except after you have the watch's battery replaced. Σ If you need to advance the analog time a long way, press D and B at the same time. This locks the high speed hand movement, so you can release the two buttons. High-speed hand movement continues until you press any button. It will also stop automatically after the time advances 12 hours or if an alarm (daily alarm, Hourly Time Signal, or countdown alarm) starts to sound. 4. Press A to exit the setting screen. Σ To return to the Timekeeping Mode, press C.